


Strength of Materials
Prof. S.K.Bhattacharya
Dept. of Civil Engineering,
I.I.T., Kharagpur
Lecture No.26
Stresses in Beams-I

Welcome to the first lesson of the 6th module which is on Stresses in Beams part 1. In the last module we had discussed some aspects of the shear force and bending moment on beams and in this particular module we are going to discuss how to utilize the information on the shear force and bending moment in evaluating the stresses in the beam.


(Refer Slide Time: 01:04-01:05)



In today's lesson we will be discussing on the effect of the bending moment on the stresses in a beam. Hence it is expected that once this particular lesson is completed, one should be able to understand the concept of bending stress in a beam and one should be in a position to derive the bending or the flexural equation.


In fact as we have seen in the case of the torsion in a shaft, when we compute the stresses in a shaft or a ball due to twisting moment, we have computed the stresses and there by we had derived the torsion formula. Now on similar lines, when a beam is subjected to a load and is undergoing a bending and shear force as we have seen when we compute the stresses and derive the formula which we call as a bending formula.

(Refer Slide Time: 01:29-02:49)



As we go along in this lesson, we will see how to derive the bending equation. Now one should be in a position to evaluate bending stress in determinate beams for different loadings. Here we are qualifying the beam by saying it is a determinate beam as we have seen that the beams which we are dealing with are the reactive forces of this particular beams. We can evaluate the values of the reactive forces based on the equations of equilibrium and hence they are determinate and in this particular course, we are dealing with mainly the determinate systems.

(Refer Slide Time: 02:49-03:18)



IIT Kharagpur


Scope

- This lesson includes:
 - Recapitulation of previous lesson.
 - Derivation of bending or flexural equation in a beam due to pure bending.
 - Examples for evaluation of bending stresses in determinate beams for different loadings.

17

Hence the scope of this particular lesson includes the recapitulation of the previous lesson as we will be discussing the aspects of the previous lessons through the question answer session. We will also be deriving the bending or the flexural equation in a beam due to pure bending. In this particular lesson, we will discuss about the pure bending and then we will looking into some examples for the evaluation of bending stresses in determinate beams for different loadings.

(Refer Slide Time: 03:19-04:06)



IIT Kharagpur


Answers to Question Set 5.4

- What is the effect of articulation in an indeterminate beam?
- What is the effect of articulation in a determinate beam?
- What is the necessity of drawing shear force and bending moment diagrams of beams?

18

Let us look into the questions which were given last time and their answers. The first question given was on the effect of articulation in an indeterminate beam. Now this is a term wherein we introduce a mechanism in a beam, where at that particular point it can sustain the shear force but it cannot resist any bending moment. What happens if we introduce this kind of articulation in a beam in an indeterminate beam? The next question is that if we introduce a similar kind of articulation in a determinate beam then what will be the consequence?


(Refer Slide Time: 04:06-09:58)



Let us look into these two questions in one go and let me answer those questions. If I have a beam which is fixed at one end and subjected to different kinds of loading say uniformly distributed load, concentrated load, a concentrated moment etc. Now as we have seen in this particular beam at this end, we have a fixed support where we have reactive forces such as the vertical force, the horizontal force and the bending moment.

This is the reactive force R, horizontal force H and moment M and all these 3 quantities can be evaluated using the equations of statics namely the summation of horizontal forces is 0, the summation of vertical forces is 0 and the summation of moment at any point within this beam is 0. If we do that we can evaluate these unknown reactive forces H M and R. So this particular system is a determinate system.

(Refer Slide Time: 05:23)



Let us suppose we introduce one roller at this particular end and thereby introduce another reactive force in this particular end; (Refer Slide Time: 05:23) let us call this as R₁ and this as R₂. Now as soon as we do this, this particular beam becomes indeterminate that is it is no longer determinate. The reason is that we have 4 unknown reactions and they are H, M, R₁ and R₂. So there are 4 unknown reactive forces and we have only 3 equations of statics. Hence this particular system is statically indeterminate.

To find a solution for such a problem, many a times we introduce another condition in a beam. Let us say that we introduce a hinge in this particular beam inside and this hinge is such that it cannot resist any moment but it can support shear force. It can support the shear force at this particular end but it cannot resist any moment.

Now as soon as we introduce this particular kind of articulation in a beam wherein it cannot resist any moment, that means we generate an additional equation from this particular condition, that means if we take the moment of all the forces about that particular point it is expected that the moment resistance will be 0.

Hence we get another equation based on which we can solve the unknown reactive forces. If you have an articulation introduced in an indeterminate beam where you have additional unknown reactive forces, then we can solve that or the beam becomes determinate in that situation.

This particular articulation can be introduced in this form. This is the beam and the other part may be resting on this in this particular form. So this particular part is fixed at this end and this is on a roller. At this particular support if you split it into two parts the reactive force from this particular part is supported on roller at this end now here we will have a reactive force. These forces are the same and if we call this r this is also r because this particular section can resist the shear force.


We can have a reactive force generator at this particular end. Now this is a determinate system having a fixed end which is a cantilever and this is like a simply supported one and these unknown reactive forces can be calculated which are the shear at this particular end. If we have an articulation in a beam, then that indeterminate beam becomes a determinate one. The beam becomes determinate because we generate an additional equation so we have four unknowns.

We get three equations of statics and 1 additional equation, so it becomes a determinate situation. Now if we have a determinate beam in which we do not have a support, it is just a cantilever. Then if we have the cantilever beam which is fixed at this particular end and let us suppose we introduce this articulation over here where again this is subjected to different kinds of loading; distributed loading and the concentrated loading or may be a concentrated moment.

If we have an articulation in this beam, that means if we have the beam again in the same form as we were discussing that you have a fixed end here and this particular part is like this. Since this particular part does not have any support, so when it is subjected to the loading, it will topple because it cannot resist any moment over here. So, a determinate beam becomes unstable when an articulation is provided in a determinate system.


This is the impact of the articulation. One should be careful that if you have an indeterminate beam and if you introduce an articulation within the beam then that indeterminate beam becomes determinate or you get an additional equation generated for every articulation you induce and if you have a determinate beam in which we introduce any articulation, it becomes unstable.

(Refer Slide Time: 09:57-10:13)



This is what is indicated over here where the introduction of articulation in an indeterminate beam reduces the beam to a determinate one and the introduction of articulation in a determinate beam reduces the beam to an unstable system.

(Refer Slide Time: 10:14-11:19)




So, that answers the first two questions. Now the third question is: What is the necessity of drawing shear force and bending moment diagrams of beams? You have gone through the previous module wherein we have discussed various kinds of loading on various kinds of beams and then we have evaluated the shear forces and bending moment at different sections.

If we need to know the variation of the shear force or the bending moment along the length of the beam and if we draw the diagram over the length of the beam where the variation of the shear force is at every section then it becomes easier to understand 'which' part of the beam is subjected to 'what' kind of shear forces or bending moment.

From the diagram of shear force or the bending moment readily, we can get the different values of bending moments and shear force along the length of the beam from which we can determine at which part the magnitude of the shear force or the bending moment is larger or smaller. Hence, for evaluating the stresses in a beam it becomes much simpler. Once we know the variation of the shear force and the bending moment in a beam, it becomes easier to compute the corresponding stresses.


(Refer Slide Time: 11:20-12:27)



In this lesson we will discuss how that induces the bending stress in the beam. So, the shear force and bending moment diagram indicate their variations respectively in a beam. The variation of the bending moment and shear force along the length of the beam and the diagram thus help in finding the maximum values of shear force or the bending moment because when we deal with stresses, we will need the maximum magnitude of the bending moment based on which we can compute the stress.

We need to know at which point for some loading in a beam the maximum bending moment occurs and for that reason, we need to draw the bending moment diagram and so is the case with the shear force.

(Refer Slide Time: 12:28-16:27)



Let us see what happens when a beam is subjected to a pure bending. We had drawn the shear force and bending moment diagram for a beam say which is simply supported and subjected to two concentrated loads which are placed equally from the two ends say distance a and a and in this particular beam, we had drawn the bending moment diagram wherein you had seen that the bending moment over this particular zone is constant.

If you have a cantilever beam in which you have a concentrated moment, you also get the same moment ' m '. So these are the cases where a beam is subjected to pure bending moment. Now when a beam is subjected to this kind of pure bending moment, then if we are interested in finding out the stresses, we need to develop the relationship between the bending moment that is acting in the beam and the corresponding stress induced in the section in terms of the sectional properties and that is what we are going to look into now.

As we made some assumption while deriving the torsion equation, we make some assumptions here as well. Let us assume that this is a part of the prismatic beam in which the cross section of this particular beam is such that it is symmetrical with respect to the vertical axis y and so this is y axis. Now this particular section here is soon in the form of a trapezium wherein this is symmetrical with respect to y axis where as it is not symmetrical with respect to z axis since x is a longer length of the member.


This is the centroid of this particular section. The axis which we draw along the centroid we call as the axis of the beam. Also along the y axis if we pass the plane the load acts and the bending which is acting in the beam are in the vertical plane. Here we assume that the section is symmetrical with respect to this vertical plane and the plane of bending is this particular plane and also in this particular plane the load acts.

So we say generally that the beam has an axial plane of symmetry, which is the $x y$ plane in this particular case and this is the plane of symmetry. That means the section is symmetrical with respect to this plane and the applied loads lie in the plane of symmetry which is what we assume over here.

As we have seen that because of the loading it will be subjected to shear force and bending moment it will undergo deformation. Now when it undergoes deformation the axis of the beam which we have chosen over here undergoes bending and we assume that it does not undergo stretching. The most important assumption which we make over here is that the cross section of the beam which was plane before the application of the load remains plane or perpendicular to the deformed axis after the bending occurs.

That means after the beam undergoes bending which forms a part of the circle and the axis also takes that particular form of the circle and anywhere if we take a section the cross section remains perpendicular to the deformed axis and the section which was plane originally, remains plane even after bending. Thus this is one of the main assumptions which you make while deriving the bending equation.

(Refer Slide Time: 16:28-22:35)



Now with these assumptions let us look into a small segment of this prismatic beam wherein it is acted on by the pure moment M . Let us say that we take a small segment out of this prismatic beam of length dx and we choose a fiber a and b and a b also is of length dx . Let us assume that a b is at a distance of y from this axis of the beam which is the x axis. Under loading let us say it under goes deformation and the deform shape is something like this which is a part of a great circle.

Let us concentrate on this particular segment which was originally dx and let us say that it undergoes deformation. Along this particular length this is ds and this axis of the beam has a radius R_{ow} with reference to the center of this great circle. The fiber a b here is a dash b dash and now here at a distance of y this also under goes deformation.

Let us assume that this particular segment forms an angle $d\theta$. Hence the radius of this particular arc is $R - y$. We can write this particular distance ds from the radius r and this angle $d\theta$ as $R d\theta$ and we can write the segmental distance ds as $(R - y) d\theta$.

If we call this as du , this is $(R - y) d\theta$. The final length - the original length which is $R d\theta$ is the deformation and we get $(R - y) d\theta$. Let us divide this by the original length and $du/ds = (R - y) d\theta / ds$ and ds as you know is $R d\theta$. So, we get $(R - y) / R$. Now du is the stretching in the curve direction and if we take its horizontal component, the angle being very small causes that angle which varies. We can call du as the axial stretching du .

Like wise the distance ds which is around the arc length has a component in the horizontal direction which is equal to the original length dx . If we substitute that this gives us the extension du over the original length dx and as we have defined the extension over the original length as a strain. We call the strain along the axial direction or normal to the cross section as normal strain which is $-y/R$.

If we call ϵ as the normal strain which $-y/R$ and R is the radius of curvature of the axis of the beam and many a times we designate this particular quantity $1/R$ as κ which we call as curvature and the strain ϵ is $-y/R$. Consequently, as we know the relationship between the stress and strain in terms of the modulus of elasticity is $\sigma = E$ multiplied by ϵ . This is as per the Hooke's law assuming that we are dealing with beams that are within their elastic limit.

So within the elastic limit stress is proportional to the strain as per the hooks law. The stress σ is equal to ϵ multiplied by E and $\epsilon = -y/R$. Here ϵ is equal to $-y/R$ and $\sigma = -E(y)/R$. These are the values of the normal strain and stress which act on the cross section of the member. Here you note that strain in the stress vary along the depth y which is the depth of the beam. From the geometrical compatibility of the beam under the geometrical deformation we understand how it undergoes strain.

This gives us a relationship which we call as compatibility. We have to look into the equations of equilibrium so that we can establish the relationship between the stress and the corresponding stress resultant which is the moment. Let us keep this aspect in mind that $\epsilon = -y/R$ and $\sigma = -E y / R$ and we need to locate where the variation of y is along the depth.

(Refer Slide Time: 22:36-28:49)



Now let us look into a segment of this beam again. We have shown three axis: the z axis, the y axis and the x axis. Let us consider a small element here having an area da . As we know that the summation of the horizontal forces $\sum F_x = 0$ and this force is nothing but the stress multiplied by the area. If we integrate these over the entire area this is 0. The σ as we have seen is $-E y / R$ ($\int \sigma da$) integral this over area which is equal to 0.

If we take out these two constants, $e - e_{\text{Row}} e$ (Row) so this over area $a y d a = 0$. Now we can write this as $a \bar{y} \text{ times this constant value } e / \text{Row} = 0$. Since area $a \neq 0$ $\bar{y} = 0$ which means that the distance of that segmental area with respect to the centroid axis or origin is 0. This can happen only if the centroid of the cross section matches with the origin.

Now this signifies that the z axis must pass through the centroid of the beam. If this $y = 0$ then from the expression of strain which we had as $-y / \text{Row}$ and Sigma as $-e y / \text{Row}$ these quantities are 0 when $y = 0$. That means at this particular point the strain and the stress is 0 and that is the reason this particular axis is termed as the neutral axis. In fact if we look into the cross section we have a point where the strain and the stress is 0 and it linearly varies in the entire depth of the beam.


We will have a variation wherein we will have a zero strain or zero stress over here and here we will have strain and corresponding stresses and this will give us the variation of the strain and the stress. This is one equation of equilibrium from which we can position or locate the neutral axis in the cross section.

For positioning the neutral axis in the cross section it should pass through the centroid of the cross section. Given a cross section which is symmetrical with respect to y axis we got to locate its centroidal point and through the centroidal point the neutral axis will pass through. This is the information which we get corresponding to this particular equilibrium equation.

Let us look into the relationship between the moment and the stress. The other equilibrium equation which we can have is the moment value. Let us take the moment of this particular area where this is the beam segment which we are assuming with a moment M and here we are considering the force which is $\sigma \times da$. So the moment of this force is $\sigma \times da$ multiplied by the distance y . If we call this distance as y then moment $M + \sigma \times da(y)$ integrated over the area is 0.

If you substitute the value of σ this is $m - e/\rho$ ($y \times d \times y$) = 0. This is nothing but $M = E/\rho$ (integral $y^2 \times da$). This integral $y^2 \times da$ is the second moment of this segmental area with reference to this neutral axis and this we designate as the moment of inertia and we call this as I . From this relationship we get $M = E I$ by ρ . Now we have already observed that in the relationship between the stress and the ρ we have $\sigma = - E y$ by ρ .


(Refer Slide Time: 28:50-29:28)



From these we can say that $\sigma/y = E/\rho$. So, $\sigma/y = - E/\rho$ and $E/\rho = M/EI$ so this is $- M/I$. So, we can write that $M/I = E/\rho = - \sigma/y$. This particular equation which relates the moment with the curvature we call as the bending equation or the moment equation. Finally this is the diagram which we get.

As we have seen that this is the plane of bending along which the load acts. We call this particular axis along which the stress is 0 as neutral axis and for each cross section if we plot this neutral axis, we get a surface which we call as neutral surface. The neutral surface of the beam which is plotted over here is the axis of the beam and this is the neutral axis of the cross section.

(Refer Slide Time: 29:29-31:46)



IIT Kharagpur

Bending Equation

- The bending equation or the flexural equation of beams is:

$$\frac{M}{I} = \frac{E}{\rho} = \frac{-\sigma}{y}$$


The bending equation which we get is this kind where the M is the bending moment, I is the moment of inertia, E is the modulus of the elasticity, ρ is the radius of the curvature of the neutral axis, σ is a stress and y is the point at the point where we are trying to find out the bending stress.

Now in a beam at a particular cross section if our interest is to evaluate the bending stress, the location of that particular point with reference to the neutral axis will be known and hence the distance y will be known. Here 'I' is the moment of inertia of the cross section with respect to the neutral axis and M is the bending moment which is acting at that particular section. Once we know these parameters, we can compute the value σ . So from these we can write that the relationship $M/I = -\sigma/y$ or $\sigma = M y/I$.

If we take a segment in the positive bending moment in the beam this particular type of moment causes compression at the top and tension at the bottom because of the bending which is acting in this particular segment. The bottom fibers undergo stretching which we call as tensile and the top fiber undergoes compression which is compressive. If we apply the positive bending moment in this particular equation we get the stress as negative and the negative stress indicates that it is compression and likewise if we compute the stress at the bottom fiber wherein y will be negative, we get the stress as positive and there by the positive stress gives us the tensile stress.

If we take the positive moment and correspondingly if we place the values of y according to the position of the point where we are evaluating the stress, the negative value of the stress will give us the compressive stress and the positive value will give us a tensile stress. These are the steps that we must go through to find out the bending stress at a point in a given cross section.

(Refer Slide Time: 31:47-34:19)



When we want to find out the stress at that particular section, we must know what is the value of the bending moment it is subjected to because of the external load that is acting on the beam. So for a particular type of a beam for which we know the support condition and the loading on the beam, we compute the value of the bending moment at a particular section where we want to evaluate the bending stress.

Once we know the value of the bending moment then for that particular cross section we have to establish the position of the neutral axis and once you know the neutral axis, you can compute the moment of inertia of that particular section and also distance y with respect to the neutral axis and we know the bending moment.

We know the distance y , we know the moment of inertia of the cross section with respect to the neutral axis, so we can compute the value of the bending stress which is $M y/I$ and this is what is indicated over here. You have to evaluate the bending moment at the point where you want to find out the stress and locate the position of the neutral axis. You will have to determine the moment of inertia of the cross section about neutral axis and you will have to determine the y coordinate of the point so that you know the distance y .

The position of the neutral axis will guide us to evaluate 'I' and y . These two parameters will be dependent on this and then we will have to compute the bending stress from this expression which is $M y/I$. We can take the appropriate sign of the corresponding parameter so that the stress can be completed. We can then conclude whether there is a compressive stress or tensile stress that is acting at that particular point. That is how you can visualize how the variation of the bending moment or shear force along the length of beam is going to help us evaluate the stress at a point in a beam which is subjected to some kinds of loading.

(Refer Slide Time: 34:20-36:31)

The slide features the IIT Kharagpur logo and name at the top. Below it, the title "Example Problem - 1" is displayed in yellow. The diagram shows a horizontal beam of total length 3m, supported at point A (left end) and point B (2m from A). A point C is located at the right end, 1m from B. A uniformly distributed load of 10kN/m is applied downwards over the entire length of the beam. The task is to draw the shear force and bending moment diagrams for this beam.

- Draw the shear force and bending moment diagram for the beam shown.


Let us take some examples wherein we can apply this technique. Now this is the example problem which in fact I had given you last time and asked you to solve. We need to draw the shear force and bending moment diagram for this particular beam and as you can see here, this is on hinged support and this is on a roller support and there is an over hand on this beam and this is subjected to a uniformly distributed load of 10 kilo Newton/m.

Here the reactive forces will have a vertical reaction R_A and we will have the horizontal reaction H_A and here we will have the vertical reaction R_B . Since we do not have any horizontal load on this, the summation of horizontal force = 0 will give us the reactive force $H_A = 0$. Now the summation of vertical force = 0 means $R_A + R_B =$ the total force which is 10 kilo Newton/m over a length of 3M and this is 30 kilo Newton.

If we take the moment of all the forces with respect to a beam, then we can get the value of the reactive force R. So, $R_A (2)$, which is a clockwise moment and this loading, causes an anti-clockwise moment and this part of the loading causes a clockwise moment. So, $R_A (2) +$ this part is $10(1) (1/2)$ which is a moment over this point and this part is $-10(2) (1) = 0$. So, this is $10(2/2)$ and this is 5 and we get -15. Here $R_A = 7.5$ kilo Newton and correspondingly from this $R_B = 22.5$ kilo Newton.

Let us look into some examples wherein we can draw the shear force and the bending moment diagram. Here $R_A + R_B = 30$ kilo Newton and $R_A = 7.5$ kilo Newton and $R_B = 22.5$ kilo Newton. Now let us take a section here at a distance of x so that we can draw the free body of that particular part and if we draw the free body of that part we get the reactive force R A.

(Refer Slide Time: 36:32-44:34)



Here, we have the shear force V , the bending moment M , the uniformly distributed load which is acting over this particular segment and the length of this segment which is x . If we take the equilibrium of the vertical forces, then we have $V + R_A - 10(x) = 0$. This gives us $V = 10x - R_A$ and $R_A = 7.5$ and we get the expression $V = 10x - 7.5$.

Correspondingly, if we calculate the value of the bending moment, we have a bending moment M acting in an anticlockwise direction. The load gives a moment in an anticlockwise direction if we take the moment with respect to this point, so $M + 10$. This is x and this distance is $x/2$ so $x^2/2 - R_A(x) = 0$. This gives us $M = 7.5(x) - 5x^2$ which is the expression for the bending moment and we have the values of the bending moment and the shear force indicated by this expression.

If we need to find out the shear force at the point B where $x = 2$ since we do not have any load in between at $x = 2$, the value of $V = 10(-7.5) = 20 - 7.5$ and this is 12.5 and this is +12.5. When $x = 0$, $V = -7.5$ and V at $x = 2$ and $V = +12.5$. It varies from -7.5 to 12.5 and somewhere in between, the shear force will be 0.

Let us suppose we need to know the point where the shear force is 0. Since we know this is the expression for the shear force between A and B; we substitute $V = 0$ so $0 = 10x - 7.5$ which gives us the value of x which $= 0.75$. At a distance of 0.75 from the left end, the value of the shear force is 0 which is indicated over here. At the point of the shear force where the value is 0 the sign changes from the positive to the negative or vice versa and these are the places where you can expect that the bending moment is going to be 0.

Here, this is one of the places where it is expected that the bending moment could be maximum. Now corresponding to the slope from 7.5 to 12.5, we get over here if you look into a section corresponding to this beyond this reactive value, what would be the value of the shear force that we get? We have R_A here, we have R_B here and we have the uniformly distributed load. Now this is the section which is at a distance of x from here and we have the section which is V and the moment M so $V + R_A + R_B - 10(x) = 0$.

So, the shear force $V = 10x - R_A - R_B$. Here x is 2; so this is $20 - 7.5 = 12.5$ and $R_A = 12.5$ and R_B is 22.5 and this is 10. We get a positive value of shear as 10 and from 12.5 to -10 it will become 0. This is the variation of the shear force and this is the shear force diagram for this particular beam.

Consequently, let us look at the value of the bending moment where $x = 0$ and the moment = 0. Now when $x = .75$, we get a value of bending moment which = 2.813 kilo Newton meter. If we substitute the value of $x = .75$, we get the value of the maximum positive bending moment. When we compute the bending moment at this particular point when $x = 2$, we find that this is $15 - 4(5) = 20$ and this is 15. This gives us a -5 kilo Newton meter and at this point, we get a bending moment which is 5 kilo Newton meter which is negative.

In a beam as we have discussed earlier you can get the values positive in the maximum value at a different point but if we are interested in the maximum possible values, then whether it is negative or positive, the maximum bending moment that is occurring in this particular section or in this particular beam is 5 kilo Newton meter.

The maximum positive bending moment is 2.813 kilo Newton meter and we get the variation of the bending moment and the variation of the shear force. If you notice here that the bending moment diagram also changes its signs from positive to negative so somewhere within this particular zone A B, the bending moment = 0.

Let us suppose we want to compute the distance that you can compute from this bending moment diagram, bending moment expression. Here we have the expression for the bending moment as $m = 7.5x - 5x^2$. Now if this moment is 0, we have $7.5x = 5x^2$. So, if we say $x = 1.5M$ at a distance of 1.5M the bending moment = 0 and this distance is 1.5M from here.

So, the magnitude of the bending moment at this point which is at this support point = 5 kilo Newton meter because of this overhand and the bending moment is 0 at a distance of 1.5M from the left support and we get the values of the bending moment and shear force for this particular problem.

(Refer Slide Time: 44:35-46:37)

The diagram shows a beam ABCDE with supports at B, C, D, and E. The beam is divided into segments AB, BC, CD, and DE. The lengths of segments AB, BC, and CD are each L, and the length of segment DE is 2L. A point load P is applied at A, and a point load Q is applied at D. The beam is supported by a hinge at B, a roller at C, a hinge at D, and a roller at E.

IIT Kharagpur

Example Problem - 2


- The two beams ABCD & DE are connected at D. The hinge at D can support shear force but can not resist bending moment. Evaluate the maximum shear force in the beam.

Now let us look at another example that I had given you last time wherein in these particular beams, we have introduced an articulation and let us look into this particular beam which is of indeterminate type this beam which is on hinge support and this on one roller support. If you look into the reactive forces here we have the vertical force here, we have the horizontal force here and we have R_B , this is R_C and this is R_E .

Now here you have a horizontal force H_A and take a look at the number of unknowns 1, 2, 3, 4 and as we have seen that we have three equations of statics and four unknown reactive values. Hence we cannot solve it using equations of statics alone which is why it is an example of an indeterminate beam. Now since we have one additional unknown equation to be evaluated we need at least another equation so that we can solve for the unknown reactive forces.

This additional equation can be generated from the criteria that it has been indicated. The beam has an articulation wherein these articulations can take the shear but cannot resist the bending moment. It will take the moment of all the forces with respect to this particular point which is 0 and then we get an additional set of equations. Basically here there are two beams which are interconnected at this particular part. So if we compute the values of the reactive forces, then we can evaluate the shear force diagram based on which we can find out the maximum shear force in the beam.

(Refer Slide Time: 46:38-51:49)



We have the diagram plotted but this particular beam has been split at the articulation and we have introduced one reactive force R_D over here. Now these two forces are balancing in nature, which means that one beam is getting supported over the other and transferring the shear force here. It can resist the shear force but it rotates when it comes for the bending.

If we are interested in finding out the values of this uniformly distributed load acting over q , we have a length $2L$ and all these segmental lengths or L and the summation of horizontal force 0 which gives you 0 . Let us take this particular part $R_D + R_E = 2qLq(L)$. So, we have one equation and from this we can say that if we take the moment of R_D with respect to this point then $R_E(2L) = q(2L)(L)$. So, $2L$ gets cancelled and $R_E = q(L)$ and there by $R_D = q(L)$. The values of the reactive forces are R_E and $R_D = q(L)$.


In the left segment the summation of vertical forces 0 will give you $R_B + R_C - R_D + P = 0$. So this gives us $R_B + R_C = R_D - P$ and $R_D = qL$ and we have $qL - P$. If you take the moment of all the forces with respect to this, then we get another set of equations for R_B and R_C and correspondingly we get the value of $R_B = -2P - qL$ and the value of R_C . Correspondingly, we get $2qL + P$ and we get the values of reactive forces where $R_E = qL$ and the shear force which acts in the articulation as $R_D = qL$.

Now if we plot the shear force and take a free body over here, we have the force P and this is V . So, $P + V = 0$ and $V = -P$ and here we have $-P$ from here to here. Since you do not have any other load, at this particular point if you take the free body we have the force which is acting over there which is P and we have the reactive force R_B . So, we have P , R_B and V here and we have $V + P + R_B = 0$. Therefore $V = -P - R_B$ and $R_B = -2P - qL$. So, this is $+2P + qL$ and that will give us a value of $P + qL$.

Here we get a shear force of magnitude $P + qL$ and from $-P$ it changes over to $+P + qL$. Then up to this segment again, the situation is the same and everywhere we have the identical shear force. Now immediately after this particular reactive force if you take the free body diagram of this particular part we have $P + R_B + R_C + P = 0$ and from there if we compute the value of V we find that it becomes again $-qL$.

Up to this it is uniform since we do not have any load in between from qL . Here it varies over the length of $2L$ and $-qL$ to $+qL$ and comes back over here. So this is the variation of the shear force over the entire length of the beam. If we note that this is the maximum value of the shear force that we get anywhere within this here it is P , here it is qL , here it is $P + qL$, the maximum value of the shear force is $P + qL$ which occurs just after this particular reactive force V which is what was asked for in this particular example.

(Refer Slide Time: 51:50-53:33)




The slide features the IIT Kharagpur logo and title at the top. Below it, the text 'Example Problem - 3' is displayed in yellow. A diagram of a beam is shown with a pin support at the left end and a roller support at the right end. The beam is divided into three equal segments of 1.0m each. A counter-clockwise moment of 5 kNm is applied at the first segment, and a downward point load of 2 kN is applied at the second segment. To the right of the beam, a rectangular cross-section is shown with a height of 80mm and a width of 50mm. Below the diagram, a bullet point states: 'The beam shown in figure has a rectangular cross section. Determine the magnitude and location of the maximum bending stress in the beam.'

Now let us look an example which is based on our discussion. In this particular beam let us call this as A B and this beam has a rectangular cross section of size 50mm/80mm. We will have to determine the magnitude and location of the maximum bending stress in the beam. First we will have to find out the magnitude and also we will have to locate where this maximum stress is occurring and this is subjected to a concentrated load 2 kilo Newton and a concentrated moment 5 kilo Newton meter.

To evaluate the value of bending stress at a point, we need to know the bending moment that is acting at that particular section. So, first we need to draw the shear force and the bending moment diagram of this particular beam. Since we have a hinged support and a roller support we have a reactive force which is a vertical reaction R_A and the horizontal reaction H_A and we have the vertical reactive force R_B over here.

If we take the summation of horizontal forces as 0, $H_A = 0$ and the summation of vertical forces will give $R_A + R_B = 2$ and if we take the moment about this particular point of all the forces we get the values of R_A . So let us compute first the reactive forces and then plot the shear force diagram so that we can compute the position of the maximum bending moment and the bending stress.

(Refer Slide Time: 53:34-56:41)



This is the reactive force R_A , the horizontal force H_A and the vertical reactive force. Here we have R_B over the beam segment A B. Now the moment about B= 0 gives us $R_A (3)$ which is a clockwise moment and class 5 kilo Newton meter which is also a clockwise moment and 2 kilo Newton meter which is an anticlockwise moment and we get 0. We get a value of $R_A = -1$ kilo Newton and as we have seen $i= 2$ kilo Newton and $R_A -1$ kilo Newton will give us the value of $R_B = 3$ kilo Newton.

These are the values of R_A and R_B . Now take a section over here which has a reactive force which is 1 kilo Newton and this being negative is in the opposite direction and we have a positive value of the shear and the moment does not change the vertical force.

You have the uniform shear which is of +1 kilo Newton. At the load point there is a change over from -1 + 1-3. So this is a 3 kilo Newton load which is shear and then finally it is constant over this particular region. So, we get the value which is the shear force diagram. If you plot the bending moment diagram correspondingly, we find that at the point of the concentrated moment from 1 kilo Newton, it changes over to 4 kilo Newton meter and here the moment comes to 3 kilo Newton meter and we get 0.


As we can see the value of the maximum bending moment is 4 kilo Newton meter and if we compute the bending stress $c = My / (Ic) = M y / (I)$. Here $M = 4$ kilo Newton meter which is $4(10 \text{ to the power of } 6)$ $y = 50$ $y = 80y = 40$ and this is $50 \times 80q/12$. The stress is 75 Mega Pascal and this bending stress here is a positive value which is why we will have compression at the top and tensile stress at the bottom. The bending causes a bending stress of 75 mpa which is located just to the right of the concentrated moment and we have a negative magnitude which is a compressive stress at the top and a tensile stress at the bottom.

We have another problem wherein we have a uniformly distributed load and a concentrated load on a simply supported beam. We will have to determine the largest allowable value of P if the bending stress is limited to 10 Mega Pascal. This problem is set for you, which we will discuss in the next lesson.

(Refer Slide Time: 56:42 - 57:00)

IIT Kharagpur

Example Problem - 4



The simply supported beam of rectangular cross section shown in figure is subjected to udl and a concentrated load. Determine the largest allowable value of P if the bending stress is limited to 10MPa.

(Refer Slide Time: 57:01-57:19)

IIT Kharagpur


Summary

This lesson included:

- Recapitulation of previous lesson.
- Concept for the bending stress and derivation of bending equation.
- Examples to evaluate bending stress for different types of loading on different types of beams.

Let us summarize this particular lesson. We have included what we have looked into in the previous lesson; we have introduced the concept of the bending stress and we have derived the bending equation and also looked into some examples to evaluate the bending stresses in a beam.

(Refer Slide Time: 57:20 – 57:30)



Now these are the following questions given for you:

What are the assumptions made in evaluating the bending stress in a beam? What is the bending equation? How do you locate neutral axis in a given cross section of a beam? We will answer these questions in the next lesson.